

# System Setup

## OVERVIEW

The **System Setup** function allows an Owner to set up equipment types, configure equipment, change screen messages, etc.

## RELATED LINKS

- [General Info](#)
- [Equipment Setup](#)
- [Screen Messages](#)
- [Technician Solutions](#)
- [Machine Information](#)
- [Additional Machine Information](#)
- [Configuration \(Equipment/Machine Setup\)](#)
- [License Key](#)

To access these functions, your specific Card ID (The 12-digit number on the back of the card) must have these functions selected in permission settings. Please see your store Owner/Manager to update your permission settings. See [Permission Settings and Functions](#) for more information on how to set permissions.